


Using the Timer

-- PAUSE VERSION --



Traditional Stopwatch

The controls on the Timer 300 work just like a stopwatch. The **go-pause** button *starts – pauses - resumes* countdown; time is refreshed with the **reset** button.

You have three convenient timer pre-sets. Program each pre-set time with the **set time** buttons on the control panel.

Pre-set times can range from 3 seconds to 9 minutes 59 seconds.

Novel Electronic Designs, Inc.
BUZZERSYSTEMS.COM